


## C377 (1)



|    | DESCRIPTION              | PART NO. | REMARKS        | *  |
|----|--------------------------|----------|----------------|----|
| 1  | TIMING BELT              | C377-01  | B150S3MK249    | 4  |
| 2  | PULLEY                   | C377-02  | P15S3M150      | 5  |
| 3  | MOTOR BKT FOR ROLLER     | C377-03  |                | 8  |
| 4  | STEPPING MOTOR           | C377-04  |                | 5  |
| 5  | IDLER BASE (Right)       | C377-05  |                | 2  |
| 6  | IDLER PULLEY             | C377-06  |                | 4  |
| 7  | MOTOR IDLER SHAFT        | C377-07  |                | 4  |
| 8  | IDLER SIDE COVER         | C377-08  |                | 4  |
| 9  | MOTOR SPACER             | C377-09  |                | 10 |
| 10 | IDLER BASE (R-UP)        | C377-10  |                | 2  |
| 11 | IDLER BASE (R-DOWN)      | C377-11  |                | 2  |
| 12 | PULLEY                   | C377-12  | P40S3M200      | 4  |
| 13 | TIMING BELT              | C377-13  | B200S3MK327    | 4  |
| 14 | BELT IDLER SHAFT         | C377-14  |                | 4  |
| 15 | PULLEY                   | C377-15  | P26S3M200      | 4  |
| 16 | TIMING BELT              | C377-16  | B200S3MK234    |    |
| 17 | SMALL IDLER SIDE PANEL   | C377-17  |                | 2  |
| 18 | SMALL IDLER BASE         | C377-18  |                |    |
| 19 | SET UP SMALL IDLER PANEL | C377-19  |                |    |
| 20 | SMALL IDLER SHAFT        | C377-20  |                |    |
| 21 | PULLEY                   | C377-21  | P60S3M200-φ 15 |    |
| 22 | CUTTER IDLER PULLEY      | C377-22  |                |    |
| 23 | TIMING BELT              | C377-23  | B150S3MK300    |    |
| 24 | SOLENOID VALVE           | C377-24  | VX2110-01-5GB  |    |
| 25 | IDLER BASE (LEFT)        | C377-25  |                | 2  |
| 26 | IDLER BASE (L-UP)        | C377-26  |                | 2  |
| 27 | IDLER BASE (L-DOWN)      | C377-27  |                | 2  |
| 28 | SENSOR BOARD BLOCK       | C377-28  |                | 2  |
| 29 | SENSOR BOARD             | C377-29  |                |    |

## C377 (2)

| 記号 | 名称                              | 注文番号    | 備考   | 使用数 |
|----|---------------------------------|---------|--|-----|
| 30 | SPRING FOR SENSOR               | C377-30 |  | 2   |
| 31 | SPACER FOR SENSOR               | C377-31 |  | 2   |
| 32 | SENSOR FITTINGS                 | C377-32 |  |     |
| 33 | CYLINDER BKT                    | C377-33 | FOR 20φ                                    | 4   |
| 34 | Cylinder Support metal fittings | C377-34 |  | 4   |
| 35 | Air Cylinder (Roller Up/Down)   | C377-35 | CQ2D20-50DC                                | 4   |
| 36 | Upper Rod adapter               | C377-36 |  | 4   |
| 37 | CYLINDER ARM (L)                | C377-37 |  | 2   |
| 38 | SET UP S ARM RINK SHAFT         | C377-38 |  | 4   |
| 39 | Down Rod adapter                | C377-39 |  | 4   |
| 40 | S ARM RINK                      | C377-40 |  | 4   |
| 41 | GEAR BOX COVER (L)              | C377-41 |  | 2   |
| 42 | GEAR BOX (L)                    | C377-42 |  | 2   |
| 43 | Gear shaft for pulley           | C377-43 | An exchange in a set of No. 43, 44 is good | 4   |
| 44 | Gear Shaft for Upper Roller     | C377-44 |  | 4   |
| 45 | SOLENOID (Roller Up/Down)       | C377-45 | VZ3123-5HS-M5-U                            | 4   |
| 46 | PLATE                           | C377-46 |  |     |
| 47 | SIDE BAR (LR)                   | C377-47 | one each of the right and left             |     |
| 48 | BELT IDLER BASE                 | C377-48 |  | 4   |
| 49 | UNDER FLAME A                   | C377-49 |  | 4   |
| 50 | Gear Shaft for Down Roller      | C377-50 |  | 4   |
| 51 | BIG SHAFT FOR CUTTER            | C377-51 |  |     |
| 52 | φ 25 × φ 15 × 9 COLLAR          | C377-52 |  | 4   |
| 53 | TIMING BELT                     | C377-53 | B300S3MK234                                |     |
| 54 | PULLEY                          | C377-54 | P60S3M-300                                 |     |
| 55 | SENSOR COLLAR FOR φ15           | C377-55 |  |     |
| 56 | ORIGIN SENSOR PLATE             | C377-56 |  |     |
| 57 | CUTTER IDLER SHAFT              | C377-57 |  |     |
| 58 | BIG IDLER BLOCK (L)             | C377-58 |  |     |
| 59 | BIG IDLER SHAFT COLLAR          | C377-59 |  | 2   |
| 60 | BIG IDLER SHAFT                 | C377-60 |  |     |
| 61 | Big Idler Adjust Block B        | C377-61 |  |     |
| 62 | Big Idler Adjust Block A        | C377-62 |  |     |
| 63 | BIG IDLER PANEL                 | C377-63 |  |     |
| 64 | BIG IDLER BLOCK (R)             | C377-64 |  |     |
| 65 | PULLEY                          | C377-65 | P24S3M-300                                 |     |
| 66 | BACK PANEL                      | C377-66 |  |     |
| 67 | GEAR BOX COVER (R)              | C377-67 |  | 2   |
| 68 | GEAR BOX (R)                    | C377-68 |  | 2   |
| 69 | CYLINDER ARM (R)                | C377-69 |  | 2   |

## C 377 (3)

| 記号 | 名称 | 注文番号 | 備考 | 使用数 |
|----|----|------|----|-----|
|----|----|------|----|-----|

|    |                                     |           |                         |   |
|----|-------------------------------------|-----------|-------------------------|---|
| 70 | FRONT PANEL                         | C377-70   | No bearing              |   |
| 71 | GAP ADJUST BASE                     | C377-71   |                         | 2 |
| 72 | Gap Bearing Holder Right            | C377-72   |                         | 2 |
| 73 | GAP ADJUST CAM B                    | C377-73   |                         | 4 |
| 74 | COARSE ROLLER                       | C377-74-A | 4pcs=1set               |   |
| 74 | COARSE FINE ROLLER                  | C377-74-B | 4pcs=1set               |   |
| 74 | SAND SHOT ROLLER                    | C377-74-C | 4pcs=1set               |   |
| 74 | URETHANE ROLLER                     | C377-74-D | 4pcs=1set               |   |
| 75 | Gap cam control                     | C377-75   |                         | 4 |
| 76 | GAP ADJUST CAM AR                   | C377-76   |                         | 2 |
| 77 | GAP ADJUSTSCREW LEFT                | C377-77   |                         | 2 |
| 78 | GUIDE PIPE HOLDER BASE              | C377-78   |                         | 4 |
| 79 | COLLAR                              | C377-79   |                         | 2 |
| 80 | GUIDE PIPE HOLDER                   | C377-80   |                         | 4 |
| 81 | NOB SHAFT                           | C377-81   |                         | 2 |
| 82 | NOB                                 | C377-82   |                         | 2 |
| 83 | GAP ADJUST NOB SHAFT                | C377-83   |                         | 2 |
| 84 | BEBEL GEAR                          | C377-84   |                         | 2 |
| 85 | GEAR BOX                            | C377-85   |                         | 2 |
| 86 | Down adjust shaft cover             | C377-86   |                         | 4 |
| 87 | Gap bearing holder Left             | C377-87   |                         | 2 |
| 88 | NOB                                 | C377-88   |                         | 2 |
| 89 | Gap adjust screw Right              | C377-89   |                         | 2 |
| 90 | GUIDE PIPE 5φ                       | C377-90-A | Right and left is commo | 2 |
| 90 | GUIDE PIPE 10φ                      | C377-90-B | Right and left is commo | 2 |
| 90 | GUIDE PIPE 13φ                      | C377-90-C | Right and left is commo | 2 |
| 90 | GUIDE PIPE 15φ                      | C377-90-D | Right and left is commo | 2 |
| 90 | GUIDE PIPE 20φ                      | C377-90-E | Right and left is commo | 2 |
| 91 | Solenoid (Guide Pipe Open/Shut)     | C377-91   | VZ1120-5G-M5            | 2 |
| 92 | Air cylinder (Guide pipe open/shut) | C377-92   | CJPB15-15D              | 2 |
| 93 | SET UP CJPB PLATE                   | C377-93   |                         | 2 |
| 94 | CJPB BKT                            | C377-94   |                         | 2 |
| 95 | SG PANEL                            | C377-95   |                         | 2 |
| 96 | PINION GEAR SHAFT                   | C377-96   |                         | 2 |
| 97 | SG GUIDE SHAFT                      | C377-97   |                         | 4 |
| 98 | GEAR BLOCK                          | C377-98   |                         | 2 |
| 99 | PINION GEAR                         | C377-99   |                         | 2 |

## C 377 (4)

| 記号  | 名称                 | 注文番号     | 備考 | 使用数 |
|-----|--------------------|----------|----|-----|
| 100 | SET UP GUIDE PLATE | C377-100 |    | 2   |

|     |                                  |            |                                   |   |
|-----|----------------------------------|------------|-----------------------------------|---|
| 100 | SET UP GUIDE PLATE FOR 23 φ      | C377-100-A |                                   | 2 |
| 101 | Left Open & Shut Guide Pipe φ5   | C377-101-A |                                   |   |
| 101 | Right Open & Shut Guide Pipe φ10 | C377-101-B |                                   |   |
| 101 | Right Open & Shut Guide Pipe φ13 | C377-101-C | standard                          |   |
| 101 | Right Open & Shut Guide Pipe φ15 | C377-101-D |                                   |   |
| 101 | Right Open & Shut Guide Pipe φ20 | C377-101-E |                                   |   |
| 102 | R LUG UPPER                      | C377-102   |                                   | 2 |
| 103 | R LUG DOWN                       | C377-103   |                                   | 2 |
| 104 | BLADE HOLDER                     | C377-104   | One each of top and bottom        |   |
| 105 | BLADE S7 (V BLADE)               | C377-105-A | top and bottom=set                |   |
| 105 | BLADE S7 (ROUND BLADE)           | C377-105-B | top and bottom=set : Size designa |   |
| 106 | Trash is removed Rear Side       | C377-106   |                                   | 2 |
| 107 | AIR PIPE                         | C377-107   | Right and left is cor             | 2 |
| 108 | YATOI UPPER                      | C377-108   |                                   |   |
| 109 | Trash is removed Front Side      | C377-109   |                                   |   |
| 110 | CUTTER BLOCK ASSY                | C377-110   | No blade, No. 104, 106~113=set    |   |
| 111 | CUTTER CASE COVER                | C377-111   |                                   |   |
| 112 | Left Open & Shut Guide Pipe φ5   | C377-112-A |                                   |   |
| 112 | Left Open & Shut Guide Pipe φ10  | C377-112-B |                                   |   |
| 112 | Left Open & Shut Guide Pipe φ13  | C377-112-C | standard                          |   |
| 112 | Left Open & Shut Guide Pipe φ15  | C377-112-D |                                   |   |
| 112 | Left Open & Shut Guide Pipe φ20  | C377-112-E |                                   |   |
| 113 | MAIN BOX COVER                   | C377-113   |                                   |   |
| 114 | CASTING Sheet (Dark blue) large  | C377-114   |                                   |   |
|     | Operation panel ASSY (Japanese)  | 07-031-01  | No. 115~118=set                   |   |
|     | Operation panel ASSY (English)   | 07-031-02  |                                   |   |
|     | Operation panel ASSY (CE)        | 07-031-03  |                                   |   |
| 115 | Power switch for CE              | 03-025-01  |                                   |   |
| 116 | Operation panel (Japanese)       | 07-001-01  |                                   |   |
| 116 | Operation panel (English)        | 07-001-02  |                                   |   |
| 117 | LCD                              | 07-002-00  |                                   |   |
| 118 | TOGGLE SWITCH                    | 03-026-00  |                                   | 4 |
|     | SAFETY COVER ASSY                | C377-118   | No. 128~138=set                   |   |
| 119 | AIR REGULATOR BLACKET            | C377-119   |                                   | 2 |
| 120 | AIR REGULATOR                    | C377-120   | LRMA-QS-6                         | 2 |
| 121 | MAIN BOX                         | C377-121   |                                   |   |
| 122 | HOLE COVER                       | C377-122   | =C371-7                           |   |
| 123 | EXIT GUIDE                       | C377-123   |                                   |   |
| 124 | FRONT SIDE COVER (L)             | C377-124   |                                   |   |
| 125 | COVER BKT (L)                    | C377-125   |                                   |   |

C 377 (5)

| 記号  | 名称                   | 注文番号     | 備考 | 使用数 |
|-----|----------------------|----------|----|-----|
| 126 | MAGNET CATCH         | C377-126 |    |     |
| 127 | SAFETY ACRYLIC COVER | C377-127 |    |     |

|     |                               |            |                             |   |
|-----|-------------------------------|------------|-----------------------------|---|
| 128 | COVER OPEN & SHUT KNOB        | C377-128   |                             |   |
| 129 | Cover open & shut base part A | C377-129   |                             |   |
| 130 | Cover open & shut base part C | C377-130   |                             |   |
| 131 | Cover open & shut base part B | C377-131   |                             |   |
| 132 | COVER BKT (R)                 | C377-132   |                             |   |
| 133 | FRONT SIDE COVER (R)          | C377-133   |                             |   |
| 134 | WIRE GUIDE RIGHT 5φ           | C377-134-A |                             |   |
| 134 | WIRE GUIDE RIGHT 10φ          | C377-134-B |                             |   |
| 134 | WIRE GUIDE RIGHT 13φ          | C377-134-C | standard                    |   |
| 134 | WIRE GUIDE RIGHT 15φ          | C377-134-D |                             |   |
| 134 | WIRE GUIDE RIGHT 20φ          | C377-134-E |                             |   |
| 135 | LIMIT SWITCH COVER            | C377-135   |                             |   |
| 136 | PHOTO INTERRUPTER             | C377-136   |                             |   |
| 137 | COVER SENSOR BOARD            | C377-137   |                             |   |
| 138 | Cover open & shut shaft       | C377-138   |                             |   |
| 139 | 5H-MDU BOARD                  | C377-139   | for C37_ series             | 5 |
| 140 | BACK COVER                    | C377-140   |                             |   |
| 141 | RELAY 100V                    | 07-141-00  |                             | 3 |
| 141 | RELAY 110V                    | 07-141-A0  |                             | 3 |
| 141 | RELAY 220V                    | 07-141-B0  |                             | 3 |
| 142 | Power board for domestic use  | 07-026-00  | with relay for 100V         |   |
| 142 | Power board for abroad        | 07-026-A0  | with relay for 110V or 220V |   |
| 143 | DUCT PLATE                    | C377-143   |                             |   |
| 144 | DUCT COVER                    | C377-144   |                             |   |
| 145 | DUCT STAY B                   | C377-145   |                             |   |
| 146 | PPW BOARD                     | C377-146   | No relay                    |   |
| 147 | Transformer                   | C377-147   |                             |   |
| 148 | FAN                           | C377-148   |                             | 3 |
| 149 | DUCT                          | C377-149   |                             |   |
| 150 | DUCT STAY A                   | C377-150   |                             |   |
| 151 | MAIN BOARD                    | 07-024-00  | CAS-M350C                   |   |
| 152 | ROM                           | C377-152   |                             |   |
| 153 | MEKA SET UP FITTINGS          | C377-153   |                             | 4 |
| 154 | HANDLE                        | C377-154   |                             | 4 |
| 155 | MAIN BASE                     | C377-155   |                             |   |
| 156 | PW BLACKET                    | C377-156   |                             |   |

## C 377 (6)

| 記号  | 名称               | 注文番号      | 備考 | 使用数 |
|-----|------------------|-----------|----|-----|
| 157 | PW-100A BOARD    | C377-157  |    | 2   |
| 158 | POWER SUPPLY BOX | C377-158  |    |     |
| 159 | TINY PULG SOCKET | 07-139-00 |    | 2   |

|     |                                    |           |                                      |  |
|-----|------------------------------------|-----------|--------------------------------------|--|
| 160 | INLET FOR DOMESTIC USE             | 07-029-00 | Japanese                             |  |
| 160 | INLET FOR GE                       | 07-029-A0 | Europe                               |  |
| 161 | CIRCUIT PROTECTOR                  | C377-161  |                                      |  |
| 162 | Power supply cord for domestic use | 07-030-00 | Japanese                             |  |
| 162 | Power supply cord for GE           | 07-030-A0 | Europe                               |  |
| 163 | SCN2 BOARD                         | C377-163  |                                      |  |
| 164 | HARNESS A                          | C377-164  | Main board (SFC connector ⇔ No. 163) |  |
| 165 | HARNESS B                          | C377-165  | No, 163⇔No, 136                      |  |
|     |                                    |           |                                      |  |
|     |                                    |           |                                      |  |
| A   | BEARING A                          | C377-166  | 608Z                                 |  |
| B   | BEARING B                          | C377-167  | 608Z                                 |  |
| C   | BEARING C                          | C377-168  | 6902Z                                |  |
| D   | BEARING D                          | C377-169  | 6002Z                                |  |
| E   | BEARING E                          | C377-170  | 6001Z                                |  |
| F   | AIR COUPLER (BIG)                  | C377-171  | EL6-PT1/8                            |  |
| G   | AIR COUPLER (SMALL)                | C377-172  | EL4-PT1/8                            |  |
| H   | JOINT                              | C377-173  | EL4-M5-M                             |  |
| I   | JOINT                              | C377-174  | EL6-M5-M                             |  |
| J   | SILENCER                           | C377-175  | AN120-M5                             |  |
| K   | ELBOW                              | C377-176  | EL-M5                                |  |
| L   | SPEED CONTROLLER                   | C377-177  | PSL4-M5 A                            |  |
| M   | ONE-TOUCH JOINT                    | C377-178  | PUM6-PM                              |  |
| N   | ONE-TOUCH JOINT                    | C377-179  | KQU-06-00                            |  |
| O   | ONE-TOUCH JOINT                    | C377-180  | PTUM-6-PM                            |  |
| P   | AIR CAPRA                          | C377-181  | CPP20-6B                             |  |
|     | ROLLER COLLAR 2mm                  | C377-182  | 8pcs=1set                            |  |
|     | ROLLER COLLAR 3mm                  | C377-183  | 8pcs=1set                            |  |
|     | ROLLER COLLAR 4mm                  | C377-184  | 8pcs=1set                            |  |